



# Installation, Start-Up and Service Instructions

## CONTENTS

	Page
<b>SAFETY CONSIDERATIONS</b> .....	1,2
<b>GENERAL</b> .....	2
<b>INSTALLATION</b> .....	2-26
<b>Step 1 — Check Jobsite</b> .....	2
<b>Step 2 — Check Unit</b> .....	17
• STORAGE	
• UNIT PROTECTION	
<b>Step 3 — Mount Unit</b> .....	17
<b>Step 4 — Wire Electrical Connections</b> .....	17
• SUPPLY VOLTAGE	
• EXTERNAL LOOP POWER CONNECTION	
• 220-V OPERATION	
<b>Step 5 — Wire Low Voltage Connections</b> .....	25
• WATER FREEZE PROTECTION	
• ACCESSORY CONNECTIONS	
• WATER SOLENOID VALVES	
• OPTIONAL WALL-MOUNTED THERMOSTAT	
• OPTIONAL PREMIERLINK™ CONTROLLER	
<b>Step 6 — Install Supply and Return Piping</b> .....	26
• SUPPLY AND RETURN HOSES	
• SUPPLY AND RETURN PIPING	
<b>Step 7 — Install Condensate Piping</b> .....	26
<b>PRE-START-UP</b> .....	27-29
<b>System Cleaning and Flushing</b> .....	27
<b>System Checkout</b> .....	27
<b>FIELD SELECTABLE INPUTS</b> .....	29,30
<b>Complete C Control Jumper Settings</b> .....	29
<b>Complete C Control DIP Switches</b> .....	29
<b>Deluxe D Control Jumper Settings</b> .....	29
<b>Deluxe D Control DIP Switches</b> .....	29
<b>Deluxe D Control Accessory Relay Configurations</b> .....	30
<b>START-UP</b> .....	30-32
<b>Operating Limits</b> .....	30
<b>Unit Start-Up</b> .....	31
<b>Flow Regulation</b> .....	31
<b>Antifreeze</b> .....	31
<b>Cooling Tower/Boiler Systems</b> .....	32
<b>Ground Coupled, Closed Loop and Plateframe Heat Exchanger Well Systems</b> .....	32
<b>OPERATION</b> .....	32,33
<b>Power Up Mode</b> .....	32
<b>Units with Aquazone Complete C Control</b> .....	32
<b>Units with Aquazone Deluxe D Control</b> .....	32
<b>COMPLETE C AND DELUXE D BOARD SYSTEM TEST</b> .....	33,34
<b>Test Mode</b> .....	33
<b>Retry Mode</b> .....	33
<b>Aquazone Deluxe D Control LED Indicators</b> .....	33
<b>SERVICE</b> .....	34-36
<b>Unit Inspection</b> .....	34
<b>System Flushing</b> .....	34
<b>Water Coil</b> .....	34

<b>Refrigerant System</b> .....	34
<b>Condenser Cleaning</b> .....	34
<b>Condensate Pans</b> .....	35
<b>Blower Motors</b> .....	35
<b>Compressor</b> .....	35
<b>Safety Control Reset</b> .....	35
<b>Checking System Charge</b> .....	36
<b>Refrigerant Charging</b> .....	36
<b>Air Coil Fan Motor Removal</b> .....	36
<b>TROUBLESHOOTING</b> .....	36-38
<b>Thermistor</b> .....	36
<b>Control Sensors</b> .....	36
<b>START-UP CHECKLIST</b> .....	CL-1, CL-2

**IMPORTANT:** Read the entire instruction manual before starting installation.

## SAFETY CONSIDERATIONS

Installation and servicing of air-conditioning equipment can be hazardous due to system pressure and electrical components. Only trained and qualified service personnel should install, repair, or service air-conditioning equipment.

Untrained personnel can perform basic maintenance functions of cleaning coils and filters and replacing filters. All other operations should be performed by trained service personnel. When working on air-conditioning equipment, observe precautions in the literature, tags and labels attached to the unit, and other safety precautions that may apply.

Improper installation, adjustment, alteration, service, maintenance, or use can cause explosion, fire, electrical shock or other conditions which may cause personal injury or property damage. Consult a qualified installer, service agency, or your distributor or branch for information or assistance. The qualified installer or agency must use factory-authorized kits or accessories when modifying this product. Refer to the individual instructions packaged with the kits or accessories when installing.

Follow all safety codes. Wear safety glasses and work gloves. Use quenching cloth for brazing operations. Have fire extinguisher available. Read these instructions thoroughly and follow all warnings or cautions attached to the unit. Consult local building codes and applicable electrical codes for special installation requirements.

Understand the signal words — DANGER, WARNING, and CAUTION. DANGER identifies the most serious hazards which will result in severe personal injury or death. WARNING signifies hazards that could result in personal injury or death. CAUTION is used to identify unsafe practices, which would result in minor personal injury or product and property damage.

**⚠ WARNING**

Electrical shock can cause personal injury or death. Before installing or servicing system, always turn off main power to system. There may be more than one disconnect switch. Turn off accessory heater power if applicable.

**GENERAL**

The 50PEC water source heat pump console unit is a decentralized room terminal designed for field connection to a closed-circuit piping loop.

Units are typically installed in perimeter zones, usually under windows. Supply air is discharged directly into the conditioned space through discharge grilles located in the top of the unit.

**IMPORTANT:** The installation of console water source heat pump units and all associated components, parts, and accessories which make up the installation shall be in accordance with the regulations of ALL authorities having jurisdiction and MUST conform to all applicable codes. It is the responsibility of the installing contractor to determine and comply with ALL applicable codes and regulations.

**INSTALLATION**

**Step 1 — Check Jobsite** — Units are typically installed along an outside wall of the room. Refer to Fig. 1 and 2 for an illustration showing piping locations. Install units with adequate clearance to allow maintenance and servicing. Refer

to Table 1 and Fig. 3-14. Locate the console unit so that it provides adequate air circulation throughout the room.

Installation, operation and maintenance instructions are provided with each unit. Before unit start-up, read all manuals and become familiar with the unit and its operation. Thoroughly check out the system before operation. Complete the inspections and instructions listed below to prepare a unit for installation.

1. Compare the electrical data on the unit nameplate with ordering and shipping information to verify that the correct unit has been shipped.
2. Keep both the chassis and cabinet covered with the shipping carton until all plastering, painting, and finish work is complete and it is time to install the chassis and cabinet.
3. Verify that the refrigerant tubing is free of kinks or dents, and that it does not touch other unit components.
4. Inspect all electrical connections. Connections must be clean and tight at the terminals.

**⚠ CAUTION**

To avoid equipment damage, do not use these units as a source of heating or cooling during the construction process. The mechanical components and filters used in these units quickly become clogged with construction dirt and debris which may cause system damage.

**⚠ CAUTION**

To avoid the release of refrigerant into the atmosphere, the refrigerant circuit of this unit must only be serviced by technicians who meet local, regional, and national proficiency requirements.

**Table 1 — 50PEC Physical Data**


BASE UNIT 50PEC	09	12	15	18
COMPRESSOR (Qty)	Rotary (1)			
REFRIG. CHARGE (R-410A)/CKT (kg)	0.737	0.822	0.936	0.850
No. of Circuits	1	1	1	1
<b>BLOWER</b>				
Motor kW	0.37	0.62	0.93	0.93
Wheel Size D x W (mm) 2 each	133 x 159	133 x 159	133 x 159	133 x 159
<b>WATER CONNECTION SIZE</b>				
OD Sweat (in.)	1/2	1/2	1/2	3/4
Optional FPT Fittings (in.)	1/2	1/2	1/2	3/4
Optional MPT Fittings (in.)	1/2	1/2	1/2	3/4
<b>CONDENSATE CONNECTION SIZE (ID Vinyl) (in.)</b>	5/8	5/8	5/8	5/8
<b>Air Coil Size (h x w) (mm)</b>	203 x 660	254 x 660	254 x 660	254 x 812
<b>FILTER SIZE (h x w x d) (mm)</b>				
Bottom Return	254 x 762 x 25	254 x 762 x 25	254 x 762 x 25	254 x 914 x 25
Front Return	178 x 749 x 3	178 x 749 x 3	178 x 749 x 3	178 x 800 x 3
<b>CABINET SIZE (h x w x d) (mm)</b>				
Bottom Return With Standard 127 mm Subbase	1219 x 660 x 305	1219 x 660 x 305	1219 x 660 x 305	1372 x 660 x 305
Front Return With No Subbase	1219 x 533 x 305	1219 x 533 x 305	1219 x 533 x 305	1372 x 533 x 305
<b>UNIT WEIGHT (kg)</b>				
Shipping	84	86	91	105
Operating	79	82	86	100
<b>Unit Maximum Working Pressure (kPa)</b>				
Base Unit	3100	3100	3100	3100
Internal Secondary Pump	999	999	999	999
Internal Motorized Water Valve	2067	2067	2067	2067
Internal Autoflow Valve	3100	3100	3100	3100

**NOTES:**


1. All units have grommet compressor mountings and TXV (thermostatic expansion valve) devices.

2. All pipe sizes are in inches. Equivalent sizes in millimeters follow:

in.	mm
1/2	12.7
5/8	15.9
3/4	19.1



**Right Hand Configuration**



**Left Hand Configuration**


**LEGEND**

**EPT** — External Pipe Thread  
**IPT** — Internal Pipe Thread


\*Dimension reduced by fitting if selected.

NOTE: Dimensions shown are in inches. Dimensions in parentheses are in millimeters.

**Fig. 1 — 50PEC09-15 Piping Dimensions**



Right Hand Configuration



Left Hand Configuration


LEGEND

- EPT — External Pipe Thread
- IPT — Internal Pipe Thread

\*Dimension reduced by fitting if selected.


NOTE: Dimensions shown are in inches. Dimensions in parentheses are in millimeters.

Fig. 2 — 50PEC18 Piping Dimensions




- NOTES:
1. Dimensions are shown in inches. Dimensions in parentheses are in millimeters.
  2. Access is reduced if optional disconnect box is selected.
  3. Optional autoflow valve, motorized water valve and disconnect box are shown.

**Fig. 3 — 50PEC09-15 Bottom Return Cabinet Dimensions — Right Hand Piping**




- NOTES:
1. Dimensions are shown in inches. Dimensions in parentheses are in millimeters.
  2. Access is reduced if optional disconnect box is selected.
  3. Optional autoflow valve, motorized water valve and disconnect box are shown.

**Fig. 4 — 50PEC18 Bottom Return Cabinet Dimensions — Right Hand Piping**



- NOTES:
1. Dimensions are shown in inches. Dimensions in parentheses are in millimeters.
  2. Access is reduced if optional disconnect box is selected.
  3. Optional autoflow valve, motorized water valve and disconnect box are shown.

**Fig. 5 — 50PEC09-15 Bottom Return Cabinet Dimensions — Left Hand Piping**




**NOTES:**

1. Dimensions are shown in inches. Dimensions in parentheses are in millimeters.
2. Access is reduced if optional disconnect box is selected.
3. Optional autoflow valve, motorized water valve and disconnect box are shown.


**Fig. 6 — 50PEC18 Bottom Return Cabinet Dimensions — Left Hand Piping**







- NOTES:
1. Dimensions are shown in inches. Dimensions in parentheses are in millimeters.
  2. Access is reduced if optional disconnect box is selected.
  3. Optional autoflow valve, motorized water valve and disconnect box are shown.

**Fig. 7 — 50PEC09-15 Front Return Cabinet Dimensions — Right Hand Piping**



- NOTES:
1. Dimensions are shown in inches. Dimensions in parentheses are in millimeters.
  2. Access is reduced if optional disconnect box is selected.
  3. Optional autoflow valve, motorized water valve and disconnect box are shown.


**Fig. 8 — 50PEC18 Front Return Cabinet Dimensions — Right Hand Piping**



NOTES:



1. Dimensions are shown in inches. Dimensions in parentheses are in millimeters.
2. Access is reduced if optional disconnect box is selected.
3. Optional autoflow valve, motorized water valve and disconnect box are shown.

**Fig. 9 — 50PEC09-15 Front Return Cabinet Dimensions — Left Hand Piping**



- NOTES:
1. Dimensions are shown in inches. Dimensions in parentheses are in millimeters.
  2. Access is reduced if optional disconnect box is selected.
  3. Optional autoflow valve, motorized water valve and disconnect box are shown.

**Fig. 10 — 50PEC18 Front Return Cabinet Dimensions — Left Hand Piping**




\*If optional subbase is selected or if unit is installed raised above the floor, add 125 mm to dimension.

NOTES:


1. Dimensions shown are in inches. Dimensions in parentheses are in millimeters.
2. Optional autoflow valve, motorized water valve and disconnect box are shown.

**Fig. 11 — 50PEC09-15 Chassis Dimensions — Bottom Return**




**Fig. 12 — 50PEC09-15 Chassis Dimensions — Front Return**

- NOTES:**
1. Dimensions shown are in inches. Dimensions in parentheses are in millimeters.
  2. Optional autoflow valve, motorized water valve and disconnect box are shown.
  3. Chassis can mount directly on floor.



**Right Hand Configuration**





**Left Hand Configuration**

\*If optional subbase is selected, add 125 mm to dimension.

**NOTES:**

1. Dimensions shown are in inches. Dimensions in parentheses are in millimeters.
2. Optional autoflow valve, motorized water valve and disconnect box are shown.

**Fig. 13 — 50PEC18 Chassis Dimensions — Bottom Return**



**NOTES:**

1. Dimensions shown are in inches. Dimensions in parentheses are in millimeters.
2. Optional autoflow valve, motorized water valve and disconnect box are shown.
3. Chassis can mount directly on floor.

**Fig. 14 — 50PEC18 Chassis Dimensions — Front Return**



**⚠ CAUTION**

All refrigerant discharged from this unit must be recovered without exception. Technicians must follow industry accepted guidelines and all local, regional, and national statutes for the recovery and disposal of refrigerants.

**⚠ CAUTION**

When a compressor is removed from this unit, system refrigerant circuit oil will remain in the compressor. To avoid leakage of compressor oil, the refrigerant lines of the compressor must be sealed after it is removed.

**Step 2 — Check Unit** — Upon receipt of shipment at the jobsite, carefully check the shipment against the bill of lading. Make sure all units have been received. Inspect the carton or crating of each unit, and inspect each unit for damage. Ensure the shipping company makes proper notation of any shortages or damage on all copies of the freight bill. Concealed damage not discovered during unloading must be reported to the shipping company within 15 days of receipt of shipment.

NOTE: It is the responsibility of the purchaser to file all necessary claims with the shipping company.

**STORAGE**

**⚠ CAUTION**

DO NOT store or install console units in corrosive environments or in locations subject to temperature or humidity extremes (e.g., attics, garages, rooftops, etc.). Corrosive conditions and high temperature or humidity can significantly reduce performance, reliability, and service life. Always move units in an upright position. Tilting units on their sides may cause equipment damage.

Upon the arrival of equipment at the jobsite, immediately store units in their shipping cartons in a clean, dry area. **Store units in an upright position at all times. Stack units a maximum of 3 units high. Use pallets to separate each layer of units. DO NOT remove equipment from shipping cartons until equipment is required for installation.**

**UNIT PROTECTION** — Cover console units on the jobsite with either shipping cartons, vinyl film, or an equivalent protective covering. Cap the open ends of pipes stored on the jobsite. In areas where painting, plastering, or the spraying of fireproof material has not been completed, all due precautions must be taken to avoid physical damage to the units and contamination by foreign material. Physical damage and contamination may prevent proper start-up and may result in costly equipment clean-up.

Examine all pipes, fittings, and valves before installing any of the system components. Remove any dirt found on these components.

**Step 3 — Mount Unit**

1. Unpack the unit from the shipping carton. Remove the front cabinet by lifting up and away from the backplate. Protect the cabinet from damage during installation by returning it to its original vinyl pack until required.
2. Remove compressor isolation plate shipping bolts (4), as shown in Fig. 15.
3. Using a carpenter's square and a level, ensure the unit is level. Shim the unit if necessary to assure proper installation.

**Poor or inadequate installation may result in noisy unit operation or unattractive appearance.**

4. Select the proper fasteners to connect the backplate securely to the wall.
5. Fasten the backplate onto the wall through the screw holes located in the back flange. Secure the subbase in place.

**Step 4 — Wire Electrical Connections**

**⚠ WARNING**

To avoid possible injury or death due to electrical shock, open the power supply disconnect switch and secure it in an open position during installation.


**⚠ CAUTION**

Use only copper conductors for field-installed electrical wiring. Unit terminals are not designed to accept other types of conductors.


All field-installed wiring, including the electrical ground, MUST comply with National Electrical Code (NEC, U.S.A.) as well as all applicable local codes. In addition, all field wiring must conform to the Class II temperature limitations described in the NEC.

Consult the unit wiring diagram located on the inside of the compressor access panel to ensure proper electrical hookup. The installing (or electrical) contractor must make the field connections shown in Fig. 16 when using field-supplied disconnect.

Refer to unit wiring diagrams Fig. 17-24 for a schematic of the field connections, which must be made by the installing (or electrical) contractor. Operating voltage must be within voltage range shown in Table 2.



**Fig. 15 — Remove 4 Shipping Bolts on Compressor Isolator Plate**



**⚠ WARNING**

Disconnect electrical power source to prevent injury or death from electrical shock.

**⚠ CAUTION**







Use copper conductors only to prevent equipment damage.

A = Two power wires.



B = 1 heat/1 cool/manual or auto changeover remote 24-V thermostat.

NOTE: All customer-supplied wiring to be copper only and must conform to national and local electrical codes. Wiring shown with dashed lines must be field-supplied and field-installed. "B" wiring only required with systems using remote-mounted thermostats.

**Fig. 16 — Typical Field-Installed Wiring**



Power Supply  
Refer to Data Plate  
Use copper  
conductors only.  
See Note 2



BLOWER MOTOR WIRING		
UNIT SIZE	POLE A	POLE B
ALL	5	4

- AL** — Alarm Relay Contacts  
**BM** — Blower Motor  
**BR** — Blower Relay  
**CAP** — Capacitor  
**CB** — Circuit Breaker  
**CO** — Sensor, Condensate Overflow  
**CR** — Compressor Relay  
**DM** — Damper Motor  
**ES** — End Switch  
**FP1** — Sensor, Water Coil Freeze Protection  
**FP2** — Sensor, Air Coil Freeze Protection  
**HPS** — High Pressure Switch  
**HPWS** — High Pressure Water Switch  
**JW1** — Jumper Wire for Alarm  
**LOC** — Loss of Charge Pressure Switch  
**PDB** — Power Distribution Block  
**RAS** — Return Air Sensor  
**RVS** — Reversing Valve Solenoid  
**TRANS** — Transformer  
**WV** — Water Valve

**LEGEND**


- Relay/Contactor Coil
- Solenoid Coil
- Thermistor
- Circuit Breaker
- Relay Contacts-N.O.
- Switch-Temperature
- Switch-High Pressure
- Switch-Low Pressure
- Ground
- Wire Nut
- Mate-N-Lok

\*Optional wiring.  
†Registered trademark of AMP Incorporated.

**NOTES:**

- Compressor and blower motor thermally protected internally.
- All wiring to the unit must comply with local codes.
- Transformer is wired to 240-V (ORG) lead for 240-1-50 units. For 220-1-50 operation, switch the RED and ORG leads at L1 and insulate the RED lead. Transformer is energy limiting or may have a circuit breaker.
- FP1 thermistor provides freeze protection for water. When using anti-freeze solutions, cut JW3 jumper.
- For remote sensor, position jumper J1 on upper 2 pins.
- For metric display, position jumper on 1 pin.
- Transformer secondary ground via GRN/YEL wire from C to control box.
- Mate-N-Lok† plug is optional.
- See view A for wiring of units with water valve (part no. 23B00112N01) or view B for units with water valve (part no. 23B00112N03).
- Factory cut jumper (JW1). Dry contact will be available between AL1 and AL2.

**Fig. 17 — 50PEC Unit Manual or Auto Changeover with Complete C Controller Wiring**



**Fig. 18 — 50PEC Unit with Complete C and LON Controllers**






Fig. 19 — 50PEC Unit with Deluxe D and LON Controllers





- LEGEND**
- AL — Alarm Relay Contacts
  - BM — Blower Motor
  - BR — Blower Relay
  - CAP — Capacitor
  - CB — Circuit Breaker
  - CO — Sensor, Condensate Overflow
  - CR — Compressor Relay
  - DM — Damper Motor
  - ES — End Switch
  - FP1 — Sensor, Water Coil Freeze Protection
  - FP2 — Sensor, Air Coil Freeze Protection
  - HPWS — High-Pressure Switch
  - HPS — High-Pressure Water Switch
  - JW4 — Jumper Wire for Alarm
  - LOC — Loss of Charge Pressure Switch
  - NLL — Night Low Limit Switch
  - PB — Power Terminal Block
  - RAS — Return Air Sensor
  - RVS — Reversing Valve Solenoid
  - TRANS — Transformer
  - WV — Water Valve
  - Field Line Voltage Wiring
  - Field Low-Voltage Wiring
  - Printed Circuit Trace



- NOTES:**
- Compressor and blower motor thermally protected internally.
  - All wiring to the unit must comply with local codes.
  - Transformer is wired to 240-V (ORG) lead for 240-1-50 units. For 220-1-50 operation, switch the RED and ORG leads at L1 and insulate the RED lead. Transformer is energy limiting or may have a circuit breaker.
  - FP1 thermistor provides freeze protection for WATER. When using anti-freeze solutions, cut JW3 jumper.
  - For remote sensor, position jumper J1 on upper 2 pins.
  - For metric display, position jumper on 1 pin.
  - Transformer secondary ground via GRN/YEL wire from C to control box.
  - See view A for wiring of units with water valve (part no. 23B00112N01) or view B for units with water valve (part no. 23B00112N03).
  - Factory cut jumper (JW4). Dry contact will be available between AL1 and AL2.

**Fig. 20 — 50PEC Unit Manual or Auto Changeover and Deluxe D Controller**



**LEGEND**

- |              |  |  |                           |
|--------------|--|--|---------------------------|
| <b>AL</b>    | — Alarm Relay Contacts                 |  | Printed Circuit Trace     |
| <b>BM</b>    | — Blower Motor                         |  | Option Low Voltage Wiring |
| <b>BR</b>    | — Blower Relay                         |  | Relay/Contactor Coil      |
| <b>CAP</b>   | — Capacitor                            |  | Solenoid Coil             |
| <b>CB</b>    | — Circuit Breaker                      |  | Thermistor                |
| <b>CO</b>    | — Sensor, Condensate Overflow          |  | Circuit Breaker           |
| <b>CR</b>    | — Compressor Relay                     |  | Relay Contacts-N.O.       |
| <b>DM</b>    | — Damper Motor                         |  | Switch-High Pressure      |
| <b>ES</b>    | — End Switch                           |  | Switch-Low Pressure       |
| <b>FP1</b>   | — Sensor, Water Coil Freeze Protection |  | Ground                    |
| <b>FP2</b>   | — Sensor, Air Coil Freeze Protection   |  | Wire Nut                  |
| <b>FSS</b>   | — Fan Speed Switch                     |  | Mate-N-Lock               |
| <b>HPS</b>   | — High-Pressure Switch                 |  |                           |
| <b>HPWS</b>  | — High-Pressure Water Switch           |  |                           |
| <b>JW1</b>   | — Jumper Wire for Alarm                |  |                           |
| <b>LOC</b>   | — Loss of Charge Pressure Switch       |  |                           |
| <b>PDB</b>   | — Power Distribution Block             |  |                           |
| <b>RVS</b>   | — Reversing Valve Solenoid             |  |                           |
| <b>TRANS</b> | — Transformer                          |  |                           |
| <b>WV</b>    | — Water Valve                          |  |                           |
|              | Field Line Voltage Wiring              |  |                           |
|              | Field Low-Voltage Wiring               |  |                           |

**\*Optional wiring.**

**NOTES:**

1. Compressor and blower motor thermally protected internally.
2. All wiring to the unit must comply with local codes.
3. Transformer is wired to 240-V (ORG) lead for 240-1-50 units. For 220-1-50 operation, switch the RED and ORG leads at L1 and insulate the RED lead. Transformer is energy limiting or may have a circuit breaker.
4. FP1 thermistor provides freeze protection for water. When using anti-freeze solutions, cut JW3 jumper.
5. Low voltage wiring must be class 1 and voltage rated equal or greater than unit supply voltage.
6. Factory cut jumper (JW1). Dry contact will be available between AL1 and AL2.
7. Transformer secondary ground via GRN/YEL wire from C to control box.
8. See view A for wiring of units with water valve (part no. 23B00112N01) or view B for units with water valve (part no. 23B00112N03).

**Fig. 21 — 50PEC Unit Remote-Mounted Thermostat with Complete C Controller Wiring**






Fig. 22 — 50PEC Unit Remote-Mounted Thermostat with Deluxe D Controller Wiring



**Fig. 23 — PremierLink™ Controller Applications with Complete C Control**



**Fig. 24 — PremierLink Controller Applications with Deluxe D Control**



**Table 2 — Electrical Data — 50PEC Units**

50PEC UNIT SIZE	VOLTAGE CODE	V-Ph-Hz	MIN/MAX VOLTAGE	COMPRESSOR			FAN MOTOR FLA	TOTAL UNIT FLA	MIN CIRCUIT AMPS	MAX FUSE/HACR
				QTY	RLA	LRA				
09	7	220/240-1-50	198-264	1	3.2	17	0.4	3.6	4.4	15.0
12	7	220/240-1-50	198-264	1	4.0	19	0.4	4.4	5.4	15.0
15	7	220/240-1-50	198-264	1	4.7	23	0.6	5.3	6.5	15.0
18	7	220/240-1-50	198-264	1	5.6	25	0.6	6.2	7.6	15.0

**LEGEND**

- FLA** — Full Load Amps
- HACR** — Heating, Air Conditioning and Refrigeration
- LRA** — Locked Rotor Amps
- RLA** — Rated Load Amps

Make all final electrical connections with a length of flexible conduit to minimize vibration and sound transmission to the building.


**SUPPLY VOLTAGE** — Operating voltage to unit must be within voltage range indicated on unit nameplate.

**EXTERNAL LOOP POWER CONNECTION** — If the unit will be connected to an external loop pump or flow controller, connect the pump to the loop pump terminal block PB1. The maximum power handling is 4 amps at 240-v. The pumps will automatically cycle as required by the unit.

**220-V OPERATION** — All 220/240-v units are factory-wired for 240-v. The transformer wiring may be switched for 220-v operation (as illustrated on the wiring diagrams) by switching the RED and ORG leads at L1.

**Step 5 — Wire Low Voltage Connections**


**WATER FREEZE PROTECTION** — The Aquazone™ control allows the field selection of source fluid freeze protection points through jumpers. The factory setting of jumper JW3 (FP1) is set for water at -1.1 C. In earth loop applications, jumper JW3 should be clipped to change the setting to 12.2 C when using antifreeze in colder earth loop applications. See Fig. 25.



**Fig. 25 — Typical Aquazone Control Board Jumper Locations**

**ACCESSORY CONNECTIONS** — Terminal labeled A on the control is provided to control accessory devices such as water valves, electronic air cleaners, humidifiers, etc. This signal operates with the compressor terminal. See Fig. 26. Refer to the specific unit wiring schematic for details.

**NOTE:** The A terminal should *only* be used with 24-v signals — not line voltage signals.




**Fig. 26 — Typical Aquazone Accessory Wiring**


**WATER SOLENOID VALVES** — An external solenoid valve(s) should be used on ground water installations to shut off flow to the unit when the compressor is not operating. A slow closing valve may be required to help reduce water hammer. Figure 26 shows typical wiring for a 24-vac external solenoid valve. Figures 27 and 28 illustrate typical slow closing water control valve wiring for Taco 500 Series and Taco ESP Series valves. Slow closing valves take approximately 60 sec. to open (very little water will flow before 45 sec.). Once fully open, an end switch allows the compressor to be energized (only on valves with end switches). Only relay or triac based electronic thermostats should be used with slow closing valves. When wired as shown, the slow closing valve will operate properly with the following notations:

1. The valve will remain open during a unit lockout.
2. The valve will draw approximately 25 to 35 VA through the “Y” signal of the thermostat.

**IMPORTANT:** Connecting a water solenoid valve can overheat the anticipators of electromechanical thermostats. Only use relay based electronic thermostats.



**Fig. 27 — AMV Valve Wiring**



**Fig. 28 — Taco SBV Valve Wiring**

**OPTIONAL WALL-MOUNTED THERMOSTAT** — The 50PEC water source heat pump units are built with standard internal thermostats in either manual changeover (MCO) or automatic changeover (ACO) configuration. Refer to Fig. 17-20.

When desired, the unit can be furnished with a 24-v control circuit which is field wired to a Carrier-supplied accessory remote thermostat. Most heat pump thermostats can be used with the controller. Use a thermostat with Y, G, O and W outputs. Refer to unit wiring diagrams in Fig. 21 and 22 and Aqua-zone™ Controls, Operation, and Troubleshooting Instructions for additional information.

Vendor installation instructions and additional installation information is shipped with each thermostat.

**NOTE:** Low-voltage wiring between the unit and the wall thermostat must comply with all applicable electrical codes (i.e., NEC and local codes), and be completed before the unit is installed.

Table 3 lists recommended wire sizes and lengths to install the thermostat. The total resistance of low-voltage wiring must not exceed 1 ohm. Any resistance in excess of 1 ohm may cause the control to malfunction because of high voltage drop.

**Table 3 — Recommended Thermostat Wire Sizes**

WIRE SIZE	MAX WIRE LENGTH*
18-Gage	20 m
16-Gage	35 m
14-Gage	60 m

\*Length = Physical distance from thermostat to unit.

**OPTIONAL PREMIERLINK™ CONTROLLER** — This direct digital controller (DDC) allows the water source heat pump to be incorporated into a Carrier Comfort Network® (CCN) system installation. PremierLink control is factory-installed with the Complete C controller, or field-installed with the Deluxe D control option. Refer to Fig. 23 and 24.

## Step 6 — Install Supply and Return Piping

### ⚠ CAUTION

To ensure proper functioning of unit and system, be sure to connect entering water to upper pipe on right-hand units. On left-hand units, connect entering water to lower pipe. Failure to do so could result in equipment damage.

**SUPPLY AND RETURN HOSES** — Optional pressure-rated hose assemblies are available for use with units. Use the following guidelines when installing supply and return hose assemblies.

1. Install supply and return hoses fitted with swivel-joint fittings at one end to prevent the hose from twisting.
2. Use male adapters to secure the hose assembly to the unit and the riser.
3. Do not allow the hose to twist during installation. Twisting may damage the hose wall or the rubber compound.

4. Use pipe joint compound sparingly on the fitting adapters' male pipe threads.
5. Prevent sealant from reaching the joint's flared surfaces.
6. Do not use pipe joint compound when Teflon\* thread tape is pre-applied to hose assemblies or when flared-end connections are used.
7. Maximum torque that may be applied to brass fittings is 40 N•m. When a torque wrench is not used, tighten brass fittings finger-tight plus one quarter turn.
8. Tighten steel fittings as necessary.
9. Use shut-off/balancing valves, flow indicators, and drain tees in the supply runout and return at each floor to aid in loop balancing and servicing.

**SUPPLY AND RETURN PIPING** — System piping **MUST** comply with all applicable codes.

1. Install a drain valve at the base of each supply and return riser to enable system flushing at start-up and during routine servicing.
2. Install shut-off/balancing valves and unions at each unit to allow unit removal for servicing.

**NOTE:** If flex hoses are used, unions are not necessary.

3. Install strainers at the inlet of each system circulating pump.

**IMPORTANT:** Since loop temperatures are normally between 15.6 C and 32.2 C, pipe sweating and heat loss do not occur at normal ambient temperature conditions. Insulation must be installed on loop water piping on those sections that run through unheated areas or are located outside the building. If loop temperatures are expected below the ambient dew point, the optional internal insulation (extended range) package must be ordered.

### ⚠ CAUTION

DO NOT bend or kink supply lines or hoses. Damage to unit may result.

4. Before making the final water connections, flush the system as described in the Pre-Start-Up section of this manual. After flushing the system, connect piping and hoses to the proper supply, return and condensate connections of the unit.

**NOTE:** When necessary, use adapters to connect hoses.

5. Install any other system components, as required, following manufacturer's instructions.
6. Reinstall the front cabinet by carefully lowering the front cabinet over the chassis onto the backplate.

**Step 7 — Install Condensate Piping** — Connect the unit condensate drain to the building condensate drain with a flexible, nonpressure-rated 5/8-in. (16 mm) ID plastic hose. Avoid kinks in this hose to ensure an unobstructed flow of condensate from the unit to the drain.

The horizontal run of the condensate hose is usually too short to pose any drainage problems, however, the horizontal run of condensate line should be pitched at least 10 mm for every 1 m of run (in the direction of flow). Avoid low points and unpitched piping since dirt collects in these areas and may cause stoppage and overflow.

Field installation of a trap or vent is not required unless specified by local codes. The 50PEC units are designed in a blow-thru configuration. The condensate drain pan is located on the outlet side of the blower so that the pressure in the drain pan is higher than the atmospheric pressure.

\* Registered trademark of DuPont.

## PRE-START-UP

**System Cleaning and Flushing** — Cleaning and flushing the unit and system is the single most important step to ensure proper start-up and continued efficient operation of the system.

### ⚠ WARNING

To prevent injury or death due to electrical shock or contact with moving parts, open unit disconnect before servicing unit.

Follow the instructions below to properly clean and flush the system:


### ⚠ CAUTION

Do not flush system through the unit. Damage to unit could result.

1. Verify that electrical power to the units is disconnected, and that the circulation pump is deenergized.
2. Connect the supply hose directly to the return riser valve. Use a single length of flexible hose, as shown in Fig. 29.

NOTE: If the length of hose is too short (i.e., the resulting connection would exceed the minimum bend radius of the hose), substitute two lengths of flexible hose joined together with a field-supplied, standard NPT coupling and the flare-fitting-to-pipe adapters provided with the hose kit (Fig. 29).

3. Open all air vents. Fill the system with water. Do not allow system to overflow. Bleed all air from the system. Check the system for leaks and repair appropriately.
4. Check and adjust the water and air level in the expansion tank.
5. Verify all strainers are in place. Start the pumps, and systematically check each vent to ensure all air is bled from the system.
6. Verify make-up water is available. Adjust make-up water appropriately to replace the air that was bled from the system. Pressure test and inspect the system for leaks and make any necessary repairs. Check and adjust the water and air level in the expansion tank.
7. Open a drain at the lowest point in the system. Adjust the make-up water replacement rate to equal the rate of bleed. Continue to bleed the system until the water appears



**Fig. 29 — Temporary Connection for Flushing System Piping**

clean or for at least three hours, whichever is longest; then, completely drain the system.

8. Refill the system with clean, chemically treated water. Since water varies for each locality, contact a local water treatment company for the correct treatment chemicals to use in the area. Set the boiler to raise the loop temperature to approximately 29.4 C.

### ⚠ CAUTION

To avoid possible damage to piping systems constructed of plastic piping DO NOT allow loop temperature to exceed 43.3 C.

Circulate the solution for a minimum of 8 to 24 hours. At the end of this period, shut off the circulating pump and drain the solution. Repeat system cleaning as necessary.

9. When the cleaning process is complete, remove the short-circuited hoses. Connect the hoses to the proper supply and return connections on each unit. Refill the system and bleed off all air.
10. Test the system pH with litmus paper. The system water should be slightly alkaline (pH 7.0 to 8.5). Add chemicals, as appropriate, to maintain acidity levels.


### ⚠ CAUTION

DO NOT use “Stop-Leak” or any similar chemical agent in this system. Addition of these chemicals to the loop water will foul the system and will inhibit unit operation.

11. When the system is successfully cleaned, flushed, refilled and bled, check the main system panels, safety cutouts and alarms. Set the controls to properly maintain loop temperatures.

**System Checkout** — When the installation is complete and the system is cleaned and flushed, follow the system checkout procedure outlined below.

1. Voltage: Ensure voltage is within the utilization range specifications of the unit compressor and fan motor.
2. System Water Temperature: Ensure temperature is within an acceptable range shown in Table 4. (When conducting this check, also verify proper heating and cooling set points.)



NOTE: Use standard coupling (field-supplied) and hose adapters to join 2 hoses.

**Table 4 — Air and Water Limits**

50PEC UNIT	COOLING (C)	HEATING (C)
Min Ambient Air	10.0	10.0
Rated Ambient Air	26.7	21.1
Max Ambient Air	37.8	29.4
Min Entering Air	10.0	10.0
Rated Entering Air, dry bulb/wet bulb	26.7/19.4	21.1
Max Entering Air, dry bulb/wet bulb	37.8/28.3	26.7
Min Entering Water	-1.1	-6.7
Normal Entering Water	29.4	21.1
Max Entering Water	43.3	32.2

NOTES:

1. Minimum air and water conditions can only be used at nominal flow rates.
2. 50PEC units may have up to two values at maximum or minimum with all other parameters at normal conditions.
3. Operating limits shown are for start-up, not continuous operation. It is assumed that such a start-up is for the purpose of bringing the space to desired occupancy temperature.

3. System Water pH: Verify system water is slightly alkaline (pH = 7.5 to 8.5). Proper pH promotes the longevity of the hoses and heat exchangers. See Table 5.
4. Closed-Type Cooling Tower (Open Tower with Heat Exchanger): Check equipment for proper temperature set points and operation.
5. Balanced Water Flow Rate to Heat Pump: Record the inlet and outlet water temperatures as each heat pump unit is started. This check will eliminate nuisance unit tripouts resulting from water velocities that are either too low or too high; it can also prevent erosive water flow rates.
6. Standby Pump: Verify the standby pump is properly installed and in operating condition.

**Table 5 — Water Quality Guidelines**

CONDITION	HX MATERIAL*	CLOSED RECIRCULATING†	OPEN LOOP AND RECIRCULATING WELL**
<b>Scaling Potential — Primary Measurement</b>			
Above the given limits, scaling is likely to occur. Scaling indexes should be calculated using the limits below.			
pH/Calcium Hardness Method	All	N/A	<b>pH &lt; 7.5 and Ca Hardness, &lt;100 ppm</b>
<b>Index Limits for Probable Scaling Situations (Operation outside these limits is not recommended.)</b>			
Scaling indexes should be calculated at 150 F for direct use and HWG applications, and at 90 F for indirect HX use. A monitoring plan should be implemented.			
Ryznar Stability Index	All	N/A	<b>6.0 - 7.5</b> If >7.5 minimize steel pipe use.
Langelier Saturation Index	All	N/A	<b>-0.5 to +0.5</b> If <-0.5 minimize steel pipe use. Based upon 150 F HWG and direct well, 85 F indirect well HX.
<b>Iron Fouling</b>			
Iron Fe <sup>2+</sup> (Ferrous) (Bacterial Iron Potential)	All	N/A	<b>&lt;0.2 ppm (Ferrous)</b> If Fe <sup>2+</sup> (ferrous) >0.2 ppm with pH 6 - 8, O <sub>2</sub> <5 ppm check for iron bacteria.
Iron Fouling	All	N/A	<b>&lt;0.5 ppm of Oxygen</b> Above this level deposition will occur.
<b>Corrosion Prevention††</b>			
pH	All	6 - 8.5 Monitor/treat as needed.	<b>6 - 8.5</b> Minimize steel pipe below 7 and no open tanks with pH <8.
Hydrogen Sulfide (H <sub>2</sub> S)	All	N/A	<b>&lt;0.5 ppm</b> At H <sub>2</sub> S>0.2 ppm, avoid use of copper and cupronickel piping of HXs. Rotten egg smell appears at 0.5 ppm level. Copper alloy (bronze or brass) cast components are okay to <0.5 ppm.
Ammonia Ion as Hydroxide, Chloride, Nitrate and Sulfate Compounds	All	N/A	<b>&lt;0.5 ppm</b>
Maximum Chloride Levels			Maximum allowable at maximum water temperature.
			50 F (10 C)      75 F (24 C)      100 F (38 C)
	Copper	N/A	<20 ppm      NR      NR
	Cupronickel	N/A	<150 ppm      NR      NR
	304 SS	N/A	<400 ppm      <250 ppm      <150 ppm
	316 SS	N/A	<1000 ppm      <550 ppm      <375 ppm
	Titanium	N/A	>1000 ppm      >550 ppm      >375 ppm
<b>Erosion and Clogging</b>			
Particulate Size and Erosion	All	<10 ppm of particles and a maximum velocity of 6 fps. Filtered for maximum 800 micron size.	<10 ppm (<1 ppm "sandfree" for reinjection) of particles and a maximum velocity of 6 fps. Filtered for maximum 800 micron size. Any particulate that is not removed can potentially clog components.
Brackish	All	N/A	Use cupronickel heat exchanger when concentrations of calcium or sodium chloride are greater than 125 ppm are present. (Seawater is approximately 25,000 ppm.)

LEGEND

- HWG** — Hot Water Generator
- HX** — Heat Exchanger
- N/A** — Design Limits Not Applicable Considering Recirculating Potable Water
- NR** — Application Not Recommended
- SS** — Stainless Steel

\*Heat exchanger materials considered are copper, cupronickel, 304 SS (stainless steel), 316 SS, titanium.

†Closed recirculating system is identified by a closed pressurized piping system.

\*\*Recirculating open wells should observe the open recirculating design considerations.

††If the concentration of these corrosives exceeds the maximum allowable level, then the potential for serious corrosion problems exists. Sulfides in the water quickly oxidize when exposed to air, requiring that no agitation occur as the sample is taken. Unless tested immediately at the site, the sample will require stabilization with a few drops of one Molar zinc acetate solution, allowing accurate sulfide determination up to 24 hours after sampling. A low pH and high alkalinity cause system problems, even when both values are within ranges shown. The term pH refers to the acidity, basicity, or neutrality of the water supply. Below 7.0, the water is considered to be acidic. Above 7.0, water is considered to be basic. Neutral water contains a pH of 7.0. To convert ppm to grains per gallon, divide by 17. Hardness in mg/l is equivalent to ppm.

7. System Control: To ensure no catastrophic system failures occur, verify system controls are functioning and the sequencing is correct.
8. Freeze Protection for Water Systems: Verify freeze protection is provided for the outdoor portion of the loop water system. Inadequate freeze protection leads to expensive repairs.

### ⚠ CAUTION

To avoid equipment damage, DO NOT leave system filled in a building without heat during the winter unless anti-freeze is added to system water. Condenser coils never fully drain by themselves and will freeze unless winterized with antifreeze.

9. System Water Loop: Verify all air is bled from the system. Air in the system impedes unit operation and causes corrosion in the system piping.
10. Unit Filters: To avoid system damage and to provide maximum performance, ensure the unit filter is clean.
11. Unit Fans: Manually rotate fans to assure free rotation. Ensure fans are properly secured to the fan shaft. Do not oil fan motors on start-up since they are lubricated at the factory.
12. System Control Center: To ensure control of the temperature set points for operation of the system's heat rejector and boiler, examine the system control and alarm panel for proper installation and operation.

### FIELD SELECTABLE INPUTS

Jumpers and DIP (dual in-line package) switches on the control board are used to customize unit operation and can be configured in the field.

**IMPORTANT:** Jumpers and DIP switches should only be clipped when power to control board has been turned off.

### Complete C Control Jumper Settings (See Fig. 17, 18, and 21)

**WATER COIL FREEZE PROTECTION (FP1) LIMIT SETTING** — Select jumper 3, (JW3-FP1 Low Temp) to choose FP1 temperature limit of -12.2 C or -1.1 C. To select -1.1 C as the temperature limit, DO NOT clip the jumper. To select -12.2 C as the limit, clip the jumper.

**ALARM RELAY SETTING** — Select jumper 1 (JW1) for connecting alarm relay terminal (AL2) to 24-vac (R) or to remain as a dry contact (no connection). To connect AL2 to R, do not clip the jumper. To set as dry contact, clip the jumper.

**Complete C Control DIP Switches** — The Complete C control has one DIP switch block with five switches. See Fig. 17, 18, and 21.

**PERFORMANCE MONITOR (PM)** — DIP switch 1 will enable or disable this feature. To enable the PM, set the switch to ON. To disable the PM, set the switch to OFF.

**STAGE 2** — DIP switch 2 will enable or disable compressor delay. Set DIP switch to OFF for Stage 2 in which the compressor will have a 3-second delay before energizing.

**SWITCH 3 AND SWITCH 4** — Not used.

**FREEZE PROTECTION (FP1)** — DIP switch 5 is used to initiate one or 3 tries for the FP1 fault. If there is water freeze protection for the water coil then DIP switch 5 can be set to lock out on the FP1 fault after one try. ON = One try. OFF = 3 tries.

### Deluxe D Control Jumper Settings (See Fig. 19, 20, and 22)

**WATER COIL FREEZE PROTECTION (FP1) LIMIT SETTING** — Select jumper 3, (JW3-FP1 Low Temp) to choose FP1 temperature limit of -12.2 C or -1.1 C. To select -1.1 C as the temperature limit, DO NOT clip the jumper. To select -12.2 C as the limit, clip the jumper.

**ALARM RELAY SETTING** — Select jumper 4 (JW4-AL2 Dry) for connecting alarm relay terminal (AL2) to 24-vac (R) or to remain as a dry contact (no connection). To connect AL2 to R, do not clip the jumper. To set as dry contact, clip the jumper.

**LOW PRESSURE SETTING** — The Deluxe D control can be configured for low pressure setting (LP). Select jumper 1 (JW1-LP Norm Open) for choosing between low pressure input normally opened or closed. To configure for normally closed operation, do not clip the jumper. To configure for normally open operation, clip the jumper.

**Deluxe D Control DIP Switches** — The Deluxe D control has 2 DIP switch blocks. Each DIP switch block has 8 switches and is labeled either S1 or S2 on the circuit board. See Fig. 19, 20, and 22.

**DIP SWITCH BLOCK 1 (S1)** — This set of switches offers the following options for Deluxe D control configuration:

**Performance Monitor (PM)** — Set switch 1 to enable or disable performance monitor. To enable the PM, set the switch to ON. To disable the PM, set the switch to OFF.

**Compressor Relay Staging Operation** — Switch 2 will enable or disable compressor relay staging operation. The compressor relay can be set to turn on with Stage 1 or Stage 2 call from the thermostat. This setting is used with dual stage units (units with 2 compressors and 2 Deluxe D controls) or in master/slave applications. In master/slave applications, each compressor and fan will stage according to its switch 2 setting. If switch is set to Stage 2, the compressor will have a 3-second delay before energizing during stage 2 demand.

**NOTE:** If DIP switch is set for Stage 2, the alarm relay will not cycle during Test mode.

**Heating/Cooling Thermostat Type** — Switch 3 provides selection of thermostat type. Heat pump or heat/cool thermostats can be selected. Select OFF for heat/cool thermostats. When in heat/cool mode, Y1 is used for Cooling Stage 1, Y2 is used for Cooling Stage 2, W1 is used for Heating Stage 1 and O/W2 is used for Heating Stage 2. Select ON for heat pump applications. In heat pump mode, Y1 used is for Compressor Stage 1, Y2 is used for Compressor Stage 2, W1 is used for Heating Stage 3 or emergency heat, and O/W2 is used for RV (heating or cooling) depending upon switch 4 setting.

**O/B Thermostat Type** — Switch 4 provides selection for heat pump O/B thermostats. O is cooling output. B is heating output. Select ON for heat pumps with O output. Select OFF for heat pumps with B output.

**Dehumidification Fan Mode** — Switch 5 provides selection of normal or dehumidification fan mode. Select OFF for dehumidification mode. The fan speed relay will remain OFF during Cooling Stage 2. Select ON for normal mode. The fan speed relay will turn on during Cooling Stage 2 in normal mode.

**Switch 6** — Not used.

**Boilerless Operation** — Switch 7 provides selection of boilerless operation and works in conjunction with switch 8. In boilerless operation mode, only the compressor is used for heating when FP1 is above the boilerless changeover temperature set by switch 8 below. Select ON for normal operation or select OFF for boilerless operation.

**Boilerless Changeover Temperature** — Switch 8 on S1 provides selection of boilerless changeover temperature set point.

Select OFF for set point of 10.0 C or select ON for set point of 4.4 C.

If switch 8 is set for 10.0 C, then the compressor will be used for heating as long as the FP1 is above 10.0 C. The compressor will not be used for heating when the FP1 is below 10.0 C and the compressor will operate in emergency heat mode, staging on EH1 and EH2 to provide heat. If a thermal switch is being used instead of the FP1 thermistor, only the compressor will be used for heating mode when the FP1 terminals are closed. If the FP1 terminals are open, the compressor is not used and the control goes into emergency heat mode.

**DIP SWITCH BLOCK 2 (S2)** — The following set of DIP switches is used to configure accessory relay options.

**Switches 1 to 3** — These DIP switches provide selection of Accessory 1 relay options. See Table 6 for DIP switch combinations.

**Table 6 — DIP Switch Block S2 — Accessory 1 Relay Options**

ACCESSORY 1 RELAY OPTIONS	DIP SWITCH POSITION		
	1	2	3
Digital NSB	Off	On	On
Water Valve — Slow Opening	On	Off	On

**LEGEND**

**NSB** — Night Setback

NOTE: All other DIP switch combinations are invalid.

**Switches 4 to 6** — These DIP switches provide selection of Accessory 2 relay options. See Table 7 for DIP switch combinations.

**Table 7 — DIP Switch Block S2 — Accessory 2 Relay Options**

ACCESSORY 2 RELAY OPTIONS	DIP SWITCH POSITION		
	4	5	6
Digital NSB	Off	On	On
Water Valve — Slow Opening	On	Off	On

**LEGEND**

**NSB** — Night Setback

NOTE: All other switch combinations are invalid.

**Auto Dehumidification Mode or High Fan Mode** — Switch 7 provides selection of auto dehumidification fan mode or high fan mode. In auto dehumidification fan mode, the fan speed relay will remain off during Cooling Stage 2 if terminal H is active. In high fan mode, the fan enable and fan speed relays will turn on when terminal H is active. Set the switch to ON for auto dehumidification fan mode or to OFF for high fan mode.

**Switch 8** — Not used.

**Deluxe D Control Accessory Relay Configurations** — The following accessory relay settings are applicable for Deluxe D control only:

**CYCLE WITH COMPRESSOR** — In this configuration, the relay will be ON any time the compressor relay is on.

**DIGITAL NIGHT SETBACK (NSB)** — In this configuration, the relay will be ON if the NSB input is connected to ground C.

NOTE: If there are no relays configured for digital NSB, then the NSB and OVR (override) inputs are automatically configured for mechanical operation.

**MECHANICAL NIGHT SETBACK** — When NSB input is connected to ground C, all thermostat inputs are ignored. A thermostat setback heating call will then be connected to the OVR input. If OVR input becomes active, then the Deluxe D control will enter night low limit (NLL) staged heating mode.

The NLL staged heating mode will then provide heating during the NSB period.

**WATER VALVE (SLOW OPENING)** — If relay is configured for water valve (slow opening), the relay will start 60 seconds prior to starting compressor relay.

**CAUTION**

To avoid equipment damage, DO NOT leave system filled in a building without heat during the winter unless anti-freeze is added to system water. Condenser coils never fully drain by themselves and will freeze unless winterized with antifreeze.

**START-UP**

Use the procedure outlined below to initiate proper unit start-up:

**IMPORTANT:** This equipment is designed for indoor installation ONLY.

**WARNING**

When the disconnect switch is closed, high voltage is present in some areas of the electrical panel. Exercise caution when working with the energized equipment.

1. Adjust all valves to the full open position and turn on the line power to all heat pump units.
2. Operate each unit in the Cooling mode first. Room temperature should be in the normal range (i.e., approximately 10.0 to 26.7 C dry bulb). Loop water temperature entering the heat pumps should be at least 4.4 C but not in excess of 43.3 C. Refer to Table 8 for more specific information on the operating parameters of units.

**IMPORTANT:** Three factors determine the operating limits of a unit: (1) return-air temperature, (2) water temperature and (3) ambient temperature. Whenever any one of these factors is at a minimum or maximum level, the other two factors must be at normal levels to ensure proper unit operation. Flow rates must be at nominal AHRI (Air Conditioning, Heating, and Refrigeration Institute) / ISO (International Organization for Standardization) / ASHRAE (American Society of Heating, Refrigerating and Air Conditioning Engineers) 13256-1 standards.

**Table 8 — Water Temperature Change Through Heat Exchanger**

WATER FLOW RATE (GPM)	COOLING RISE (°C)		HEATING DROP (°C)	
	Min	Max	Min	Max
For Closed Loop: Ground Source or Cooling/Boiler Systems at 3.9 L/m per kW	5.0	6.7	2.2	4.4
For Open Loop: Ground Water Systems at 2.0 L/m per kW	11.1	14.4	5.6	9.4

**Operating Limits**

**ENVIRONMENT** — This equipment is designed for indoor installation ONLY.

**POWER SUPPLY** — A voltage variation of ± 10% of nameplate utilization voltage is acceptable.

**50PEC UNIT STARTING CONDITIONS** — The 50PEC units will start and operate at an ambient temperature of 10.0 C with entering-air temperature at 10.0 C, entering water at 15.6 C, and with both air and water at the flow rates used in the

AHRI/ISO/ASHRAE Standard 13256-1 rating test, for initial start-up in winter.

**IMPORTANT:** These operating limits are not normal or continuous operating conditions. It is assumed that such a start-up is for the purpose of bringing the building space up to occupancy temperature.

### Unit Start-Up

1. Turn the thermostat fan position to “ON”. Blower should start.
2. Balance air flow at registers.
3. Adjust all valves to their full open positions. Turn on the line power to all heat pumps.
4. Room temperature should be within the minimum and maximum ranges of Table 4. During start-up checks, loop water temperature entering the heat pump should be between 16 C and 35 C.
5. Two factors determine the operating limits of Carrier heat pumps, return air temperature and water temperature. When any one of these factors is at a minimum or maximum level, the other factor must be at normal level to ensure proper unit operation.
  - a. Adjust the unit thermostat to the warmest setting. Place the thermostat mode switch in the “COOL” position. Slowly reduce thermostat setting until the compressor activates.
  - b. Check for cool air delivery at the unit grille within a few minutes after the unit has begun to operate. Units have a five minute time delay in the control circuit that can be eliminated on the control board if needed.
  - c. Check the elevation and cleanliness of the condensate lines. Dripping may be a sign of a blocked line. Check that the condensate trap is filled to provide a water seal.
  - d. Check the temperature of both entering and leaving water. See Table 8. If temperature is within range, proceed with the test. If temperature is outside the range, check refrigerant pressures.
  - e. Check air temperature drop across the air coil when compressor is operating. Air temperature drop should be between 8° C and 14° C.
  - f. Turn thermostat to “OFF” position. A hissing noise indicates proper functioning of the reversing valve.
6. Allow five (5) minutes between tests for pressure to equalize before beginning heating test.
  - a. Adjust the thermostat to the lowest setting. Place the thermostat mode switch in the “HEAT” position.
  - b. Slowly raise the thermostat to a higher temperature until the compressor activates.
  - c. Check for warm air delivery within a few minutes after the unit has begun to operate.
  - d. Refer to Table 8. Check the temperature of both entering and leaving water. If temperature is within range, proceed with the test. If temperature is outside the range, check refrigerant pressures.
  - e. Check air temperature rise across the air coil when compressor is operating. Air temperature rise should be between 11° C and 17° C.
  - f. Check for vibration, noise, and water leaks.
7. If unit fails to operate, perform troubleshooting analysis (see troubleshooting section). If the check described fails to reveal the problem and the unit still does not operate,

contact a trained service technician to ensure proper diagnosis and repair of the equipment.

When testing is complete, set system to maintain desired comfort level.

**Flow Regulation** — Flow regulation can be accomplished by two methods. Most water control valves have a built-in flow adjustment valve. Determine the flow rate by measuring the pressure drop through the unit heat exchanger. See Table 9. Adjust the water control valve until a flow of 2.0 to 3.9 L/m per kW cooling is achieved. Since the pressure constantly varies, two pressure gages may be needed.

An alternative method for regulating flow is to install a flow control device. These devices are typically an orifice of plastic material mounted on the outlet of the water control valve, designed to allow a specified flow rate. Occasionally these valves produce a velocity noise that can be reduced by applying some back pressure. To accomplish this, slightly close the leaving isolation valve of the water regulating device.

**CAUTION**

DO NOT use “Stop Leak” or any similar chemical agent in this system. Addition of these chemicals to the loop water will foul the system and inhibit unit operation.

**Antifreeze** — In areas where entering loop temperatures drop below 4.4 C or where piping will be routed through areas subject to freezing, antifreeze is needed.

Alcohols and glycols are commonly used as antifreeze agents. Freeze protection should be maintained to 8.3° C below the lowest expected entering loop temperature. For example, if the lowest expected entering loop temperature is -1.1 C, the leaving loop temperature would be -5.6 to -3.9 C. Therefore, the freeze protection should be at -9.4 C (-1.1 C - 8.3 C = -9.4 C).

**IMPORTANT:** All alcohols should be pre-mixed and pumped from a reservoir outside of the building or introduced under water level to prevent alcohols from fuming.

Calculate the total volume of fluid in the piping system. See Table 10. Use the percentage by volume in Table 11 to determine the amount of antifreeze to use. Antifreeze concentration should be checked from a well mixed sample using a hydrometer to measure specific gravity.

**Table 9 — Coaxial Water Pressure Drop**

50PEC UNIT SIZE	L/m	PRESSURE DROP (kPa)			
		-1 C	10 C	21 C	32 C
09	4.2	11.0	8.3	6.9	6.2
	6.1	17.9	15.2	13.8	13.1
	8.7	31.0	26.2	24.1	20.7
12	5.7	14.5	12.4	10.3	9.0
	8.7	31.0	26.2	24.1	20.7
	11.4	46.9	40.0	33.8	31.0
15	7.2	10.3	6.9	6.2	5.5
	10.6	20.7	15.8	13.8	11.7
	14.0	32.4	26.9	22.7	20.0
18	8.7	15.2	12.4	10.3	9.0
	12.9	30.3	26.2	23.4	20.7
	17.1	47.5	41.3	35.8	33.1

**Table 10 — Approximate Fluid Volume (L) per 30 M of Pipe**

PIPE	DIAMETER (in.) [mm]	VOLUME (gal.) [L]
<b>Copper</b>	1 [25.4]	4.1 [15.5]
	1.25 [31.8]	6.4 [24.2]
	1.5 [38.1]	9.2 [34.8]
<b>Rubber Hose</b>	1 [25.4]	3.9 [14.8]
<b>Polyethylene</b>	3/4 IPS SDR11	2.8 [10.6]
	1 IPS SDR11	4.5 [17.0]
	1 1/4 IPS SDR11	8.0 [30.8]
	1/2 IPS SDR11	10.9 [41.3]
	2 IPS SDR11	18.0 [68.1]
	1 1/4 IPS SCH40	8.3 [31.4]
	1 1/2 IPS SCH40	10.9 [41.3]
2 IPS SCH40	17.0 [64.4]	

**LEGEND**

- IPS** — Internal Pipe Size
- SCH** — Schedule
- SDR** — Standard Dimensional Ratio

NOTE: Volume of heat exchanger is approximately 3.78 liters.

**Table 11 — Antifreeze Percentages by Volume**

ANTIFREEZE	MINIMUM TEMPERATURE FOR FREEZE PROTECTION (C)			
	-12.2	-9.4	-6.7	-3.9
Methanol (%)	25	21	16	10
100% USP Food Grade Propylene Glycol (%)	38	30	22	15
Ethanol (%)	29	25	20	14

**FREEZE PROTECTION SELECTION** — The -1.1 C FP1 factory setting (water) should be used to avoid freeze damage to the unit.

Once antifreeze is selected, the JW3 jumper (FP1) should be clipped on the control to select the low temperature (antifreeze -12.2 C) set point to avoid nuisance faults.

**Cooling Tower/Boiler Systems** — These systems typically use a common loop maintained at 15.6 C to 32.2 C. Carrier recommends using a closed circuit evaporative cooling tower with a secondary heat exchanger between the tower and the water loop. If an open type cooling tower is used continuously, chemical treatment and filtering will be necessary.

**Ground Coupled, Closed Loop and Plateframe Heat Exchanger Well Systems** — These systems allow water temperatures from -1.1 to 43.3 C. The external loop field is divided up into 50 mm polyethylene supply and return lines. Each line has valves connected in such a way that upon system start-up, each line can be isolated for flushing using only the system pumps. Air separation should be located in the piping system prior to the fluid re-entering the loop field.

**OPERATION**

**Power Up Mode** — The unit will not operate until all the inputs, terminals and safety controls are checked for normal operation.

NOTE: The compressor will have a 5-minute anti-short cycle delay upon power up.

**Units with Aquazone™ Complete C Control**

**STANDBY** — The Y and W terminals are not active in Standby mode, however the O and G terminals may be active, depending on the application. The compressor will be off.

**COOLING** — The Y and O terminals are active in Cooling mode. After power up, the first call to the compressor will initiate a 5 to 80-second random start delay and a 5-minute anti-short cycle protection time delay. After both delays are complete, the compressor is energized.

NOTE: On all subsequent compressor calls the random start delay is omitted.

**HEATING STAGE 1** — Terminal Y is active in Heating Stage 1. After power up, the first call to the compressor will initiate a 5 to 80-second random start delay and a 5-minute anti-short cycle protection time delay. After both delays are complete, the compressor is energized.

NOTE: On all subsequent compressor calls the random start delay is omitted.

**HEATING STAGE 2** — To enter Stage 2 mode, terminal W is active (Y is already active). Also, the G terminal must be active or the W terminal is disregarded. The compressor relay will remain on and EH1 (emergency heat) is immediately turned on. EH2 will turn on after 10 minutes of continual Stage 2 demand.

NOTE: EH2 will not turn on (or if on, will turn off) if FP1 (freeze protection) temperature is greater than 7.2 C and FP2 is greater than 43.3 C.

**EMERGENCY HEAT** — In Emergency Heat (EH) mode, terminal W is active while terminal Y is not. Terminal G must be active or the W terminal is disregarded. EH1 is immediately turned on. EH2 will turn on after 5 minutes of continuous emergency heat demand.

**Units with Aquazone Deluxe D Control**

**STANDBY/FAN ONLY** — The compressor will be off. The fan enable, fan speed, and reversing valve (RV) relays will be on if inputs are present. If there is a Fan 1 demand, the fan enable will immediately turn on. If there is a Fan 2 demand, the fan enable and fan speed will immediately turn on.

NOTE: DIP switch 5 on S1 does not have an effect upon Fan 1 and Fan 2 outputs.

**HEATING STAGE 1** — In Heating Stage 1 mode, the fan enable and compressor relays are turned on immediately. Once the demand is removed, the relays are turned off and the control reverts to Standby mode. If there is a master/slave or dual compressor application, all compressor relays and related functions will operate per their associated DIP switch 2 setting on S1.

**HEATING STAGE 2** — In Heating Stage 2 mode, the fan enable and compressor relays remain on. The fan speed relay is turned on immediately and turned off immediately once the demand is removed. The control reverts to Heating Stage 1 mode. If there is a master/slave or dual compressor application, all compressor relays and related functions will operate per their associated DIP switch 2 setting on S1.

**HEATING STAGE 3** — In Heating Stage 3 mode, the fan enable, fan speed and compressor relays remain on. The EH1 output is turned on immediately. With continuing Heat Stage 3 demand, EH2 will turn on after 10 minutes. EH1 and EH2 are turned off immediately when the Heating Stage 3 demand is removed. The control reverts to Heating Stage 2 mode.

Output EH2 will be off if FP1's temperature is greater than 7.2 C AND FP2 (when shorted) is greater than 43.3 C during Heating Stage 3 mode. This condition will have a 30-second recognition time. Also, during Heating Stage 3 mode, EH1, EH2, fan enable, and fan speed will be ON if G input is not active.

**EMERGENCY HEAT** — In Emergency Heat mode, the fan enable and fan speed relays are turned on. The EH1 output is turned on immediately. With continuing emergency heat demand, EH2 will turn on after 5 minutes. Fan enable and fan speed relays are turned off after a 60-second delay. The control reverts to Standby mode.

Output EH1, EH2, fan enable, and fan speed will be ON if the G input is not active during Emergency Heat mode.

**COOLING STAGE 1** — In Cooling Stage 1 mode, the fan enable, compressor and RV relays are turned on immediately. If configured as stage 2 (DIP switch set to OFF) then the compressor and fan will not turn on until there is a stage 2 demand. The fan enable and compressor relays are turned off



immediately when the Cooling Stage 1 demand is removed. The control reverts to Standby mode. The RV relay remains on until there is a heating demand. If there is a master/slave or dual compressor application, all compressor relays and related functions will track with their associated DIP switch 2 on S1.

**COOLING STAGE 2** — In Cooling Stage 2 mode, the fan enable, compressor and RV relays remain on. The fan speed relay is turned on immediately and turned off once the Cooling Stage 2 demand is removed. The control reverts to Cooling Stage 1 mode. If there is a master/slave or dual compressor application, all compressor relays and related functions will track with their associated DIP switch 2 on S1.

**NIGHT LOW LIMIT (NLL) STAGED HEATING** — In NLL staged Heating mode, the override (OVR) input becomes active and is recognized as a call for heating and the control will immediately go into a Heating Stage 1 mode. With an additional 30 minutes of NLL demand, the control will go into Heating Stage 2 mode. With another additional 30 minutes of NLL demand, the control will go into Heating Stage 3 mode.

### COMPLETE C AND DELUXE D BOARD SYSTEM TEST

System testing provides the ability to check the control operation. The control enters a 20-minute Test mode by momentarily shorting the test pins. All time delays are reduced by a factor of 15.

**Test Mode** — To enter Test mode on Complete C or Deluxe D controls, cycle the fan 3 times within 60 seconds. The LED (light-emitting diode) will flash a code representing the last fault when entering the Test mode. The alarm relay will

also power on and off during Test mode. See Tables 12-14. To exit Test mode, short the terminals for 3 seconds or cycle the power 3 times within 60 seconds.

**NOTE:** The Deluxe D control has a flashing code and alarm relay cycling code that will both have the same numerical label. For example, flashing code 1 will have an alarm relay cycling code 1. Code 1 indicates the control has not faulted since the last power-off to power-on sequence.

**Retry Mode** — In Retry mode, the status LED will start to flash slowly to signal that the control is trying to recover from an input fault. The control will stage off the outputs and try to again satisfy the thermostat used to terminal Y. Once the thermostat input calls are satisfied, the control will continue normal operation.

**NOTE:** If 3 consecutive faults occur without satisfying the thermostat input call to terminal Y, the control will go into lockout mode. The last fault causing the lockout is stored in memory and can be viewed by entering Test mode.

**Aquazone™ Deluxe D Control LED Indicators** — There are 3 LED indicators on the Deluxe D control: **STATUS LED** — Status LED indicates the current status or mode of the Deluxe D control. The Status LED light is green.

**TEST LED** — Test LED will be activated any time the Deluxe D control is in Test mode. The Test LED light is yellow.

**FAULT LED** — Fault LED light is red. The fault LED will always flash a code representing the last fault in memory. If there is no fault in memory, the fault LED will flash code 1 and appear as 1 fast flash alternating with a 10-second pause. See Table 14.

**Table 12 — Complete C Control Current LED Status and Alarm Relay Operations**

LED STATUS	DESCRIPTION OF OPERATION	ALARM RELAY
<b>On</b>	Normal Mode	Open
	Normal Mode with PM Warning	Cycle (Closed 5 sec, Open 25 sec)
<b>Off</b>	Complete C Control is non-functional	Open
<b>Slow Flash</b>	Fault Retry	Open
	Over/Under Voltage Shutdown	Open (Closed after 15 minutes)
<b>Fast Flash</b>	Lockout	Closed
<b>Flashing Code 1</b>	Test Mode — No fault in memory	Cycling Code 1
<b>Flashing Code 2</b>	Test Mode — HP Fault in memory	Cycling Code 2
<b>Flashing Code 3</b>	Test Mode — LP Fault in memory	Cycling Code 3
<b>Flashing Code 4</b>	Test Mode — FP1 Fault in memory	Cycling Code 4
<b>Flashing Code 5</b>	Test Mode — FP2 Fault in memory	Cycling Code 5
<b>Flashing Code 6</b>	Test Mode — CO Fault in memory	Cycling Code 6
<b>Flashing Code 7</b>	Test Mode — Over/Under shutdown in memory	Cycling Code 7
<b>Flashing Code 8</b>	Test Mode — PM in memory	Cycling Code 8
<b>Flashing Code 9</b>	Test Mode — FP1/FP2 swapped fault in memory	Cycling Code 9

**LEGEND**

**CO** — Condensate Overflow  
**FP** — Freeze Protection  
**HP** — High Pressure  
**LED** — Light-Emitting Diode  
**LP** — Low Pressure  
**PM** — Performance Monitor

**NOTES:**

1. Slow flash is 1 flash every 2 seconds.
2. Fast flash is 2 flashes every 1 second.
3. EXAMPLE: "Flashing Code 2" is represented by 2 fast flashes followed by a 10-second pause. This sequence will repeat continually until the fault is cleared.

**Table 13 — Complete C Control LED Code and Fault Descriptions**

LED CODE	FAULT	DESCRIPTION
<b>1</b>	No fault in memory	There has been no fault since the last power-off to power-on sequence
<b>2</b>	High-Pressure Switch	HP open instantly
<b>3</b>	Low-Pressure Switch	LP open for 30 continuous seconds before or during a call (bypassed for first 60 seconds)
<b>4</b>	Freeze Protection Coax — FP1	FP1 below temp limit for 30 continuous seconds (bypassed for first 60 seconds of operation)
<b>5</b>	Freeze Protection Air Coil — FP2	FP2 below temp limit for 30 continuous seconds (bypassed for first 60 seconds of operation)
<b>6</b>	Condensate overflow	Sensor overflow (grounded) for 30 continuous seconds
<b>7 (Autoreset)</b>	Over/Under Voltage Shutdown	"R" power supply is <19-vac or >30-vac
<b>8</b>	PM Warning	Performance monitor Warning has occurred.
<b>9</b>	FP1 and FP2 Thermistors are swapped	FP1 temperature is higher than FP2 in heating/test mode, or FP2 temperature is higher than FP1 in cooling/test mode.

**LEGEND**

**FP** — Freeze Protection  
**HP** — High Pressure  
**LED** — Light-Emitting Diode  
**LP** — Low Pressure  
**PM** — Performance Monitor

**Table 14 — Aquazone™ Deluxe D Control Current LED Status and Alarm Relay Operations**

DESCRIPTION	STATUS LED (Green)	TEST LED (Yellow)	FAULT LED (Red)	ALARM RELAY
Normal Mode	On	Off	Flash Last Fault Code in Memory	Open
Normal Mode with PM	On	Off	Flashing Code 8	Cycle (closed 5 sec, open 25 sec, ...)
D Control is non-functional	Off	Off	Off	Open
Test Mode	—	On	Flash Last Fault Code in Memory	Cycling Appropriate Code
Night Setback	Flashing Code 2	—	Flash Last Fault Code in Memory	—
ESD	Flashing Code 3	—	Flash Last Fault Code in Memory	—
Invalid T-stat Inputs	Flashing Code 4	—	Flash Last Fault Code in Memory	—
No Fault in Memory	On	Off	Flashing Code 1	Open
HP Fault	Slow Flash	Off	Flashing Code 2	Open
LP Fault	Slow Flash	Off	Flashing Code 3	Open
FP1 Fault	Slow Flash	Off	Flashing Code 4	Open
FP2 Fault	Slow Flash	Off	Flashing Code 5	Open
CO Fault	Slow Flash	Off	Flashing Code 6	Open
Over/Under Voltage	Slow Flash	Off	Flashing Code 7	Open (closed after 15 minutes)
HP Lockout	Fast Flash	Off	Flashing Code 2	Closed
LP Lockout	Fast Flash	Off	Flashing Code 3	Closed
FP1 Lockout	Fast Flash	Off	Flashing Code 4	Closed
FP2 Lockout	Fast Flash	Off	Flashing Code 5	Closed
CO Lockout	Fast Flash	Off	Flashing Code 6	Closed

**LEGEND**

- |                          |                            |
|--------------------------|----------------------------|
| CO — Condensate Overflow | LED — Light-Emitting Diode |
| ESD — Emergency Shutdown | LP — Low Pressure          |
| FP — Freeze Protection   | PM — Performance Monitor   |
| HP — High Pressure       |                            |

**NOTES:**

1. If there is no fault in memory, the Fault LED will flash code 1.
2. Codes will be displayed with a 10-second Fault LED pause.
3. Slow flash is 1 flash every 2 seconds.
4. Fast flash is 2 flashes every 1 second.
5. EXAMPLE: "Flashing Code 2" is represented by 2 fast flashes followed by a 10-second pause. This sequence will repeat continually until the fault is cleared.

**SERVICE**

Perform the procedures outlined below periodically, as indicated.

**⚠ WARNING**

To prevent injury or death due to electrical shock or contact with moving parts, open unit disconnect switch before servicing unit.

**IMPORTANT:** When a compressor is removed from this unit, system refrigerant circuit oil will remain in the compressor. To avoid leakage of compressor oil, the refrigerant lines of the compressor must be sealed after it is removed.

**IMPORTANT:** All refrigerant discharged from this unit must be recovered without exception. Technicians must follow industry accepted guidelines and all local, state and federal statutes for the recovery and disposal of refrigerants.

**IMPORTANT:** To avoid the release of refrigerant into the atmosphere, the refrigerant circuit of this unit must only be serviced by technicians who meet local, state and federal proficiency requirements.

**Unit Inspection** — Visually inspect the unit at least once a month. Pay special attention to hose assemblies. Repair any leaks and replace deteriorated hoses immediately. Note any signs of deterioration or cracking.

**System Flushing** — Properly clean and flush system periodically. Refer to Pre-Start-Up, System Cleaning and Flushing section.

**Water Coil** — Keep air out of the water coil. Check open loop systems to be sure the well head is not allowing air to infiltrate the water line. Always keep lines airtight.

Inspect heat exchangers regularly and clean more frequently if the unit is located in a "dirty" environment. The heat

exchanger should be kept full of water at all times. Open loop systems should have an inverted P trap placed in the discharge line to keep water in the heat exchanger during off cycles. Closed loop systems must have a minimum of 100 kPa during the summer and 275 kPa during the winter.

Check P trap frequently for proper operation.

**FILTERS** — Inspect filters. Establish a regular maintenance schedule. Clean or replace filters frequently depending on need.

To remove the filter from the 50PEC unit, slide the filter out of its frame located in the return air opening at the bottom front of the unit. When re-installing the filter, use the slide-in rails of the filter frame to guide the filter into the proper position.

**⚠ CAUTION**

To avoid fouled machinery and extensive unit clean-up, DO NOT operate units without filters in place. DO NOT use equipment as a temporary heat source during construction.

**Refrigerant System** — Verify air and water flow rates are at proper levels before servicing. To maintain sealed circuitry integrity, do not install service gages unless unit operation appears abnormal.

**Condenser Cleaning** — Water-cooled condensers may require cleaning of scale (water deposits) due to improperly maintained closed-loop water systems. Open water tower systems may require removal of sludge build-up due to induced contaminants.

Local water conditions may cause excessive fouling or pitting of tubes. Therefore, condenser tubes should be cleaned at least once a year, or more often if the water is contaminated.

Use standard coil cleaning procedures which are compatible with both the heat exchanger material and copper water lines. Generally, the more water flowing through the unit, the less chance for scaling, however flow rates over 3 gpm per ton can

produce water (or debris) velocities that can erode the heat exchanger wall and ultimately produce leaks.

Proper water treatment can minimize tube fouling and pitting. If such conditions are anticipated, water treatment analysis is recommended. Refer to the Carrier System Design Manual, Part 5, for general water conditioning information.

**CAUTION**


Follow all safety codes. Wear safety glasses and rubber gloves when using inhibited hydrochloric acid solution. Observe and follow acid manufacturer's instructions.

Clean condensers with an inhibited hydrochloric acid solution. The acid can stain hands and clothing, damage concrete, and, without inhibitor, damage steel. Cover surroundings to guard against splashing. Vapors from vent pipe are not harmful, but take care to prevent liquid from being carried over by the gases.

Warm solution acts faster, but cold solution is just as effective if applied for a longer period.

**GRAVITY FLOW METHOD** — Do not add solution faster than vent can exhaust the generated gases.

When condenser is full, allow solution to remain overnight, then drain condenser and flush with clean water. Follow acid manufacturer's instructions. See Fig. 30.




**Fig. 30 — Gravity Flow Method**

**FORCED CIRCULATION METHOD** — Fully open vent pipe when filling condenser. The vent may be closed when condenser is full and pump is operating. See Fig. 31.

Regulate flow to condenser with a supply line valve. If pump is a nonoverloading type, the valve may be fully closed while pump is running.

For average scale deposit, allow solution to remain in condenser overnight. For heavy scale deposit, allow 24 hours. Drain condenser and flush with clean water. Follow acid manufacturer's instructions.



**Fig. 31 — Forced Circulation Method**

**Condensate Pans** — Check condensate drain pans for algae growth every three months. If algae growth is apparent, consult a water treatment specialist for proper chemical treatment. The application of an algacide every three months will typically eliminate algae problems in most locations. Check condensate hose for leaks and blockage and correct any problems.

**Blower Motors** — All units have lubricated fan motors. **BLOWER MOTORS SHOULD NEVER BE LUBRICATED UNLESS OBVIOUS, DRY OPERATION IS SUSPECTED.** Periodic maintenance oiling is not recommended because it will result in dirt accumulating on excess oil and cause eventual motor failure. Conduct annual dry operation check and amperage check to ensure amp draw is no more than 10% greater than that indicated by serial plate data.

**Compressor** — Conduct an amperage check annually on the compressor and fan motor. Amperage draw should not exceed normal full load amps. Maintain a log of amperage to detect deterioration prior to component failure.

**Safety Control Reset** — The 50PEC heat pumps are furnished with high-pressure, low-pressure and low-temperature cutouts to prevent the machine from operating at abnormal conditions of temperature or water flow.

The contacts of the high-pressure control used on 50PEC units are designed to open at 2592 kPa and automatically re-close at 2096 kPa. The Complete C or Deluxe D control monitors this and other functions such as refrigerant temperatures and pressures and condensate overflow and will interrupt unit heating or cooling operation.

The machine must be reset manually. Reset is accomplished by pressing the STOP button and then pushing either HI HEAT, LOW HEAT, HI COOL or LO COOL to restart the unit in the desired mode of operation. (The 50PEC unit can also be reset by opening and closing the supply power disconnect switch.)

**IMPORTANT:** If the unit must be reset more than twice, check the unit for a dirty filter, abnormal entering water temperature, inadequate or excessive water flow, and internal malfunctions. If the unit continues to cut out, contact a trained service technician.

**⚠ WARNING**

When replacing the compressor contactor or lockout relay in a unit with electromechanical controls, use only Carrier factory authorized parts. Substitution of other components may result in an inoperative safety circuit and may cause a hazardous condition.

**Checking System Charge** — Units are shipped with full operating charge. If recharging is necessary:

1. Insert thermometer bulb in insulating rubber sleeve on liquid line near filter drier. Use a digital thermometer for all temperature measurements. DO NOT use a mercury or dial-type thermometer.
2. Connect pressure gage to discharge line near compressor.
3. After unit conditions have stabilized, read head pressure on discharge line gage.

NOTE: Operate unit a minimum of 15 minutes before checking charge. From standard field-supplied Pressure-Temperature chart for R-410A, find equivalent saturated condensing temperature.

4. Read liquid line temperature on thermometer, then subtract from bubble point temperature. The difference equals subcooling temperature.

**Refrigerant Charging**

**⚠ WARNING**

To prevent personal injury, wear safety glasses and gloves when handling refrigerant. Do not overcharge system — this can cause compressor flooding.

NOTE: Do not vent or depressurize unit refrigerant to atmosphere. Remove and recover refrigerant following accepted practices.

**Air Coil Fan Motor Removal**

**⚠ CAUTION**

Before attempting to remove fan motors or motor mounts, place a piece of plywood over evaporator coils to prevent coil damage.

Motor power wires need to be disconnected from motor terminals before motor is removed from unit.


1. Shut off unit main power supply.
2. Loosen bolts on mounting bracket so that fan belt can be removed.
3. Loosen and remove the 2 motor mounting bracket bolts on left side of bracket.
4. Slide motor/bracket assembly to extreme right and lift out through space between fan scroll and side frame. Rest motor on a high platform such as a step ladder. Do not allow motor to hang by its power wires.

**TROUBLESHOOTING**


When troubleshooting problems with a WSHP, consider the following and refer to Table 15.

**Thermistor** — A thermistor may be required for single-phase units where starting the unit is a problem due to low voltage. See Fig. 32 for thermistor nominal resistance.

**Control Sensors** — The control system employs 2 nominal 10,000 ohm thermistors (FP1 and FP2) that are used for freeze protection. Be sure FP1 is located in the discharge fluid and FP2 is located in the air discharge. See Fig. 33.



**Fig. 32 — Thermistor Nominal Resistance**



**Fig. 33 — FP1 and FP2 Thermistor Location**

**Table 15 — Troubleshooting**

FAULT	HEATING	COOLING	POSSIBLE CAUSE	SOLUTION			
<b>Main Power Problems</b>	X	X	Green Status LED Off	Check line voltage circuit breaker and disconnect.			
				Check for line voltage between L1 and L2 on the contactor.			
				Check for 24-vac between R and C on controller.			
				Check primary/secondary voltage on transformer.			
<b>HP Fault — Code 2 High Pressure</b>		X	Reduced or no water flow in cooling	Check pump operation or valve operation/setting. Check water flow adjust to proper flow rate.			
			X	Water temperature out of range in cooling	Bring water temperature within design parameters.		
	X		Reduced or no airflow in heating	Check for dirty air filter and clean or replace. Check fan motor operation and airflow restrictions. Dirty air coil — construction dust, etc. Perform preventative maintenance; Clean air coil. High external static. Check duct design and downstream interference.			
				X	Air temperature out of range in heating	Bring return-air temperature within design parameters.	
				X	X	Overcharged with refrigerant	Check superheat/subcooling vs. typical operating condition.
	X	X	Bad HP switch	Check switch continuity and operation. Replace.			
<b>LP Fault — Code 3 Low Pressure/Loss of Charge</b>	X	X	Insufficient charge	Check for refrigerant leaks.			
	X		Compressor pump down at start-up	Check charge and start-up water flow.			
<b>FP1 Fault — Code 4 Water Freeze Protection</b>	X		Reduced or no water flow in heating	Check pump operation or water valve operation/setting. Plugged strainer or filter. Clean or replace. Check water flow adjust to proper flow rate.			
				X	Inadequate antifreeze level	Check antifreeze density with hydrometer.	
				X	Improper freeze protect setting (-1.1 C vs -12.2 C)	Clip JW3 jumper for antifreeze (-12.2 C) use.	
	X		Water temperature out of range	Bring water temperature within design parameters.			
	X	X	Bad thermistor	Check temperature and impedance correlation.			
	<b>FP2 Fault — Code 5 Air Coil Freeze Protection</b>		X	Reduced or no airflow in cooling	Check for dirty air filter and clean or replace. Check fan motor operation and airflow restrictions. High external static. Check duct design and downstream interference.		
					X	Air temperature out of range	Too much cold vent air. Bring entering-air temperature within design parameters.
					X	Improper freeze protect setting (-1.1 C vs -12.2 C)	Normal airside applications will require -1.1 C only.
X		X	Bad thermistor	Check temperature and impedance correlation.			
<b>Condensate Fault — Code 6</b>	X	X	Blocked drain	Check for blockage and clean drain.			
	X	X	Improper trap	Check trap dimensions and location ahead of vent.			
		X	Poor drainage	Check for piping slope away from unit. Check slope of unit toward outlet. Poor venting. Check vent location.			
				X	Moisture on sensor	Check for moisture shorting to air coil.	
<b>Over/Under Voltage — Code 7 (Auto Resetting)</b>	X	X	Under voltage	Check power supply and 24-vac voltage before and during operation. Check power supply wire size. Check compressor starting. Check 24-vac and unit transformer tap for correct power supply voltage.			
				X	X	Over voltage	Check power supply voltage and 24 vac before and during operation. Check 24-vac and unit transformer tap for correct power supply voltage.
				X		Heating mode FP2> 51.7 C	Check for poor airflow or overcharged unit.
		X	Cooling mode FP1> 51.7 C OR FP2< 4.4 C	Check for poor water flow or airflow.			
<b>No Fault Code Shown</b>	X	X	Compressor overload	Check and replace if necessary.			
	X	X	Control board	Reset power and check operation.			
<b>Unit Short Cycles</b>	X	X	Dirty air filter	Check and clean air filter.			
	X	X	Unit in Test mode	Reset power or wait 20 minutes for auto exit.			
	X	X	Unit selection	Unit may be oversized for space. Check sizing for actual load of space.			
	X	X	Compressor overload	Check and replace if necessary.			
<b>Only Fan Runs</b>	X	X	Thermostat position	Ensure thermostat set for heating or cooling operation.			
	X	X	Unit locked out	Check for lockout codes. Reset power.			
	X	X	Compressor overload	Check compressor overload. Replace if necessary.			
	X	X	Thermostat wiring	Check Y and W wiring at heat pump. Jumper Y and R for compressor operation in Test mode.			

**LEGEND**

- FP — Freeze Protection
- HP — High Pressure
- LED — Light-Emitting Diode
- LP — Low Pressure
- RV — Reversing Valve

**Table 15 — Troubleshooting (cont)**

FAULT	HEATING	COOLING	POSSIBLE CAUSE	SOLUTION
<b>Only Compressor Runs</b>	X	X	Thermostat wiring	Check G wiring at heat pump. Jumper G and R for fan operation. Check Y and W wiring at heat pump. Jumper Y and R for compressor operation in Test mode.
	X	X	Fan motor relay	Jumper G and R for fan operation. Check for line voltage across BR contacts. Check fan power enable relay operation (if present).
	X	X	Fan motor	Check for line voltage at motor. Check capacitor.
<b>Unit Does Not Operate in Cooling</b>		X	Reversing valve	Set for cooling demand and check 24-vac on RV coil and at control. If RV is stuck, run high pressure up by reducing water flow and while operating engage and disengage RV coil voltage to push valve.
		X	Thermostat setup	Check for 'O' RV setup not 'B'.
		X	Thermostat wiring	Check O wiring at heat pump. Jumper O and R for RV coil.
<b>Insufficient Capacity/ Not Cooling or Heating Properly</b>	X	X	Dirty filter	Replace or clean.
	X		Reduced or no airflow in heating	Check for dirty air filter and clean or replace.
				Check fan motor operation and airflow restrictions.
				High external static. Check duct design and downstream interference.
		X	Reduced or no airflow in cooling	Check for dirty air filter and clean or replace.
				Check fan motor operation and airflow restrictions.
				High external static. Check duct design and downstream interference.
	X	X	Leaky ductwork	Check supply and return-air temperatures at the unit and at distant duct registers if significantly different, duct leaks are present.
	X	X	Low refrigerant charge	Check superheat and subcooling.
	X	X	Restricted metering device	Check superheat and subcooling. Replace.
		X	Defective reversing valve	Perform RV touch test.
	X	X	Thermostat improperly located	Check location and for air drafts behind thermostat.
	X	X	Unit undersized	Recheck loads and sizing check sensible cooling load and heat pump capacity.
X	X	Scaling in water heat exchanger	Perform scaling check and clean if necessary.	
X	X	Inlet water too hot or cold	Check load, loop sizing, loop backfill, ground moisture.	
<b>High Head Pressure</b>	X		Reduced or no airflow in heating	Check for dirty air filter and clean or replace.
				Check fan motor operation and airflow restrictions.
				High external static. Check duct design and downstream interference.
		X	Reduced or no water flow in cooling	Check pump operation or valve operation/setting.
				Check water flow adjust to proper flow rate.
		X	Inlet water too hot	Check load, loop sizing, loop backfill, ground moisture.
	X		Air temperature out of range in heating	Bring return-air temperature within design parameters.
		X	Scaling in water heat exchanger	Perform scaling check and clean if necessary.
	X	X	Unit overcharged	Check superheat and subcooling. Reweigh in charge.
X	X	Non-condensables in system	Vacuum system and reweigh in charge.	
<b>Low Suction Pressure</b>	X		Reduced water flow in heating	Check superheat and subcooling. Replace.
				Check pump operation or water valve operation/setting.
				Plugged strainer or filter. Clean or replace.
	X		Water temperature out of range	Check water flow adjust to proper flow rate.
				Bring water temperature within design parameters.
		X	Reduced airflow in cooling	Check for dirty air filter and clean or replace.
		Check fan motor operation and airflow restrictions.		
	X	Air temperature out of range	High external static. Check duct design and downstream interference.	
	X	Insufficient charge	Too much cold vent air. Bring entering air temperature within design parameters.	
<b>Low Discharge Air Temperature in Heating</b>	X		Insufficient charge	Check for refrigerant leaks.
	X		Too high airflow	Check blower.
<b>High Humidity</b>		X	Poor performance	See 'Insufficient Capacity' above.
		X	Too high airflow	Check blower.
		X	Unit oversized	Recheck loads and sizing check sensible cooling load and heat pump capacity.

**LEGEND**

- FP — Freeze Protection
- HP — High Pressure
- LED — Light-Emitting Diode
- LP — Low Pressure
- RV — Reversing Valve

**50PEC UNIT  
START-UP CHECKLIST**

CUSTOMER: \_\_\_\_\_ JOB NAME: \_\_\_\_\_  
MODEL NO.: \_\_\_\_\_ SERIAL NO.: \_\_\_\_\_ DATE: \_\_\_\_\_

**I. PRE-START-UP**

DOES THE UNIT VOLTAGE CORRESPOND WITH THE SUPPLY VOLTAGE AVAILABLE? (Y/N) \_\_\_\_\_

HAVE THE POWER AND CONTROL WIRING CONNECTIONS BEEN MADE AND TERMINALS TIGHT? (Y/N) \_\_\_\_\_

HAVE WATER CONNECTIONS BEEN MADE AND IS FLUID AVAILABLE AT HEAT EXCHANGER? (Y/N) \_\_\_\_\_

HAS PUMP BEEN TURNED ON AND ARE ISOLATION VALVES OPEN? (Y/N) \_\_\_\_\_

HAS CONDENSATE CONNECTION BEEN MADE AND IS A TRAP INSTALLED? (Y/N) \_\_\_\_\_

IS AN AIR FILTER INSTALLED? (Y/N) \_\_\_\_\_

**II. START-UP**

IS FAN OPERATING WHEN COMPRESSOR OPERATES? (Y/N) \_\_\_\_\_

**UNIT VOLTAGE — COOLING OPERATION**

PHASE AB VOLTS \_\_\_\_\_

PHASE AB AMPS \_\_\_\_\_

**CONTROL VOLTAGE**


IS CONTROL VOLTAGE ABOVE 21.6 VOLTS? (Y/N) \_\_\_\_\_.  
IF NOT, CHECK FOR PROPER TRANSFORMER CONNECTION.

**TEMPERATURES**


FILL IN THE ANALYSIS CHART ATTACHED.

COAXIAL HEAT EXCHANGER	COOLING CYCLE:						
	WATER IN	_____ C	WATER OUT	_____ C	_____ kPa	_____ L/m	
	HEATING CYCLE:						
	WATER IN	_____ C	WATER OUT	_____ C	_____ kPa	_____ L/m	
AIR COIL	COOLING CYCLE:						
	AIR IN	_____ C	AIR OUT	_____ C			
	HEATING CYCLE:						
	AIR IN	_____ C	AIR OUT	_____ C			

## HEATING CYCLE ANALYSIS



## COOLING CYCLE ANALYSIS



### HEAT OF EXTRACTION (ABSORPTION) OR HEAT OF REJECTION =

$$\text{FLOW RATE (L/m)} \times \text{TEMP. DIFF. (DEG. C)} \times \text{FLUID FACTOR*} = \text{_____ (kW)}$$

**SUPERHEAT** = SUCTION TEMPERATURE – SATURATED SUCTION TEMPERATURE  
= \_\_\_\_\_ (DEG C)

**SUBCOOLING** = SATURATED CONDENSING TEMPERATURE – LIQUID LINE TEMPERATURE  
= \_\_\_\_\_ (DEG C)

\*Use 500 for water, 485 for antifreeze.

CUT ALONG DOTTED LINE